

## Library overview

Note that the stack comments added is the stack while loading the mentioned source code chapter. Library stack comments, some library chapters need data in the stack to configure the chapter. Below is an overview of the used stack comments:

name = String to be parsed from the input stream  
ccc<ch> = String to be parsed delimited by the character 'ch'  
a = Address  
a b c etc. = Anonymus stack items  
ch = ASCII character number  
d = Double number  
+n = Positive number  
n = Signed number  
u = Unsigned number  
f = Flag ( 0 or -1 )  
pin = GPIO pin number  
i\*x j\*x = Undefined stack contents

The basic word for using the library are:

CHAPTERS = Show all available code chapters  
NEED ( ccc -- ) = Check if code chapter "ccc" was already loaded, when not add that chapter to noForth  
RUN ( ccc -- ) = Interpret the chapter "ccc" using noForth

## Tools

Tools function	Description
COPYRIGHT ( -- )	Copyright message
VERSION ( -- )	Library version info
UART ( -- )	Switch back to UART interface
TRY ADD ( -- )	Two pseudonyms for NEED & RUN
RESTORE-LIB ( -- )	Restore end of tools library pointer
OPEN-LIB ( -- )	Words to extend this library
WIPE-LIB ( -- )	Words to extend this library

<b>Tools function</b>	<b>Description</b>
CLOSE-LIB ( -- )	Words to extend this library
CHAPTERS ( -- )	Words to extend this library
ALPHA ( -- )	Show library in alphabetic order
-CHAPTERS ( -- )	Show library in reverse order
NEED( ( -- )	Multi name version of NEED
EXAMINE ( -- )	Show source code belonging to "name"
LOOK-AT ( -- )	Pseudonym for EXAMINE
VIEW ( -- )	Pseudonym for EXAMINE
PIN ( pin -- )	Change 'pin' number for S?
48MHZ ( -- )	Change clock to 48 MHz
125MHZ ( -- )	Change clock to 125 MHz
132MHZ ( -- )	Change clock to 132 MHz
250MHZ ( -- )	Change clock to 250 MHz
38K4 ( -- )	Change baudrate to 38400 baud
115K2 ( -- )	Change baudrate to 115200 baud
460K8 ( -- )	Change baudrate to 460800 baud
921K6 ( -- )	Change baudrate to 921600 baud
BAUD ( u -- )	Change baudrate to baudrate u from stack
-ROT ( -- )	Rotate top item to third on the stack
ROLL ( -- )	Move x-th item on the stack to the top
2TUCK ( -- )	Copy d2 below d1
2ROT ( -- )	Rotate third item to top of the stack
-2ROT ( -- )	Rotate top item to third on the stack
ON OFF ( -- )	Set or clear the cell at 'addr'
2! ( -- )	Store the double dx at 'addr'
2@ ( -- )	Read the double dx from 'addr'
0> ( -- )	'f' is true when n is signed greater than zero
ARSHIFT ( -- )	Arithmetic right shift by +n positions
D- ( -- )	Subtract d2 from d1 leaving d3
M+ ( -- )	Add n to d1 leaving d2
DLSHIFT DRSHIFT ( -- )	Double logical left & right shift
SM/REM ( -- )	Symmetric division with remainder
2LOG ( -- )	Calculate binary logarithm y of u
CHARS ( -- )	Add character address calculation

<b>Tools function</b>	<b>Description</b>
ERASE ( -- )	Erase +n bytes from addr
J K ( -- )	Nested loop indexes
PAD ( -- )	Scratch pad area of 32 bytes
SOURCE ( -- )	Input source manipulation words
CASE ( -- )	The CASE statement word set
UNUSED ( -- )	Leave free dictionary space
WORD ( -- )	Parse the string delimited by ch leave it at a
[COMPILE] ( -- )	Compile the word behind it always
ABORT" ( -- )	Error message with inline string
[IF] ( -- )	Interactive control structure word set
FORTH-WORDLIST ( -- )	Compilation wordlist manipulation
GET-ORDER ( -- )	Manipulate search order word set
SEARCH-WORDLIST ( -- )	Search for wordname in given wordlist id
-TRAILING ( -- )	Cut trailing spaces from a string
.S ( -- )	Non-destructive display of data stack
[DEFINED] ( -- )	Check if a word exist
[UNDEFINED] ( -- )	Check if a word not exist
CRC ( -- )	RP2040 style CRC generator
RANDOM ( -- )	32-bit pseudo random Marsaglia generator, including CHOOSE ( u1 – u2 )
THENS ( -- )	Close all open IFs
.BYTE ( -- )	Print byte number in hexadecimal
.HEX ( -- )	Print number unsigned in hexadecimal
PCHAR ( -- )	Convert all data to printable characters
MANY ( -- )	Redo current input line until a key was hit
STOP? ( -- )	Leave flag when a key was pressed, hold on a space, abort on Esc.
RECUR ( -- )	For use with for-next, it manipulates the index using keys from the keyboard
DMP ( -- )	Simple dump routine, needs address only
DUMP ( -- )	Classic Forth dump tool
WORDS ( -- )	Show words in top vocabulary
@NAME ( -- )	Read counted string from a header
>NFA ( -- )	Try to convert an address to name field address

<b>Tools function</b>	<b>Description</b>
?TEXT ( -- )	Search for inline text string
?HEAD ( -- )	Check for a valid header at given address
.DATA ( -- )	Print data word as chars and hexadecimal
SEE ( -- )	noForth decompiler
.VOCS ( -- )	Show all present vocabularies
.SHIELDS ( -- )	Show all present shields
TOOLS\ ( -- )	Add basic noForth tool set
LARGE-TOOLS ( -- )	Add extended noForth tool set
ALLWORDS ( -- )	16 times WORDS in noForth using kangaroo method
MEMMAP ( -- )	Show noForth memory map
.CFG ( -- )	Show noForth configuration
LAST\ ( -- )	Remove code behind the last present shield
-FLY ( -- )	Make all control structures interactive
COMMACODE ( -- )	Build assembler less code definitions
DAS\ ( -- )	Complete RP2040 disassembler
ASM\ ( -- )	noForth RP2040 T(humb) assembler
+ASM\ ( -- )	RP2040 assembler extension
PIO\ ( -- )	RP2040 PIO (dis)assembler v2
PIOBASE\ ( -- )	Minimal PIO control wordset v2
-LITERAL ( -- )	Literal compiler, base addr. and offset
\$VARIABLE ( -- )	String manipulation word set
-TAIL -HEAD ( -- )	Cut characters from a string
BITARRAY ( -- )	Bit array word set, for compact on/off noting and operators to handle this array
*COPY ( -- )	Copy any bit array to another, etc.
COUNT* ( -- )	Count the bits set in given bit array
*UP? ( -- )	Get the bit number of the lowest bit set & true and clear that bit, otherwise leave false
(? ( -- )	Debugging through run-time stack check
?TASK ( -- )	Check if a task is valid
TASK ( -- )	Add, start & change background tasks
TASKS ( -- )	Multitasker tools wordset
LOCK ( -- )	Semaphores, tools for sharing devices

<b>Tools function</b>	<b>Description</b>
TASKER\ ( -- )	Add complete multitasker wordset
SET-FREQ ( -- )	Set CPU frequency from 12MHz to 400MHz
TESTER\ ( -- )	Add adapted Hayes test suite
TRACER\ ( -- )	Very basic number tracer with independent number conversion ( .B .DUMP etc. )
IMAGE ( -- )	Generate Intel-Hex from current boot image It can be converted to a UF2 with a small Win32Forth program
IMAGE+ ( -- )	Idem IMAGE but saves library too
MEASURE\ ( -- )	Measure timing of code parts
USB\ ( -- )	USB CDC driver using multitasker

# Hardware

<b>Hardware function</b>	<b>Description</b>
CORE\ ( -- )	Add inter core communication
CORE1\ ( -- )	A blinker running on core-1
CORE0 ( -- )	A counter running on core-0
CORE1 ( -- )	A counter display program running on core-1
BUTTON ( -- )	A switch running on one core
BLINK ( -- )	Simple GPIO25 flashing LED demo
ADC ( -- )	Using the onboard ADC
BOOTKEY? ( -- )	Reuse BOOTSEL switch for Forth input
TEMPERATURE ( -- )	Use the built-in temperature sensor demo
PWM-ON ( pin -- )	Onboard dual PWM usage example on GPIO & GPIO + 1
ALARM ( -- )	Using the alarm registers as interval timer
KHZ> ( -- )	Convert spi-clock to divider values
LOOPBACK ( -- )	Loopback mode for spi-0 on/off
SPI\ ( rx-pin 0 1 -- )	spi-0 or spi-1 driver
I2C\ ( clock sda-pin -- )	Built-in I2C on all clock speeds
I2C-SLAVE\ ( sda-pin -- )	I2C slave implementation, needs wanted SDA pin number on the stack
IO-SLAVE ( -- )	I2C PCF8574 style slave driver
COUNTER ( -- )	I2C slave demo (master code part) set clock frequency & SDA pin number on the stack
MDMP ( -- )	I2C slave demo (master code part) set clock frequency & SDA pin number on the stack
MEM-SLAVE ( -- )	Implements an I2C memory slave, shares a memory part over the I2C-bus
>PCF8574 ( -- )	PCF8574 driver primitives
RUNNER ( -- )	A few PCF8574 demo drivers
24C02\ ( -- )	Small I2C-eeprom code example
EEPROM ( -- )	An eeprom code example
DEV? ( -- )	Check if a device is present on the I2C-bus
SCAN-I2C ( -- )	An i2c bus scanner
PCF8591\ ( -- )	I2C analog input & output using a PCF8591
LM75\ ( -- )	I2C temperature measuring with LM75

<b>Hardware function</b>	<b>Description</b>
WS2812 ( -- )	Control two WS2812 LEDs separately
WS2812START\ ( -- )	Self starting dual WS2812 PIO driver
WS2812MULTI\ ( -- )	Self starting dual WS2812 PIO driver using the multitasker
( -- )	Read & compile 16-bit character row
( -- )	Read & compile 8-bit character row
'GRAPH ( -- )	Graphic characters of 8x4 pixels
'SMALL ( -- )	Small characters set of 8x5 bits
'THIN ( -- )	A 16x6 thin character set
'BOLD ( -- )	A 16x8 bold character set
{OLED ( -- )	OLED driver for GPIO16 and SPI-0
OLED-SPI\ ( -- )	Primitive SPI OLED text driver
I2C-OLED\ ( -- )	Primitive I2C OLED text driver
&CR ( -- )	Add a scrolling display redefining the words &CR & &PAGE
THIN ( -- )	Output 16x6 thin characters
BOLD ( -- )	Output 16x8 bold characters
SMALL ( -- )	Output 8x5 small characters
GRAPHIC ( -- )	Output 8x4 graphic characters
SMALL-DEMO ( -- )	Small character scrolling demo
SCROLL-DEMO ( -- )	Thin character scrolling demo
MIXED-DEMO ( -- )	Mixed character size scrolling demo
THIN-DEMO ( -- )	Large thin character size scrolling demo
BOLD-DEMO	Large bold character size scrolling demo
GRAPHIC-DEMO ( -- )	Display graphic character set
EGEL-DEMO ( -- )	Moving hedgehog demo
SPI-OLED-DEMO\ ( -- )	Add all demos for an SPI OLED screen
I2C-OLED-DEMO\ ( -- )	Add all demos for an I2C OLED screen
OLED-APP\ ( -- )	Self starting OLED app
ST7789\ ( pin -- )	240 x 280 TFT driver using SPI from pin
BAMBOE\ ( pin #bamboe -- )	Parallel output driver with serial input

# PIO

<b>PIO function</b>	<b>Description</b>
BIT-TOGGLE1 ( sm pio pin -- )	Simple but flexible bit toggle
BIT-TOGGLE2 ( pin -- )	More advanced bit toggle on SM0 & PIO0
BIT-TOGGLE3 ( pin -- )	Idem 2 but with use of side-set & set
IN&OUT1 ( pin -- )	Use GPIO to activate GPIO+1
IN&OUT2 ( pin -- )	Toggle GPIO+1 using MOV, only
IN&OUT3 ( pin -- )	Toggle GPIO+1 using WAIT, & MOV,
IRQ-1 ( pin -- )	Two communicating programs using IRQ
IRQ-2 ( pin -- )	Idem 1, but using wrap function
MUSIC-0 ( pin -- )	Frequency generation using 4 GPIO's on 4 SM's uses clone
ON&OFF-1 ( pin -- )	Example of PIN? and MOV, toggles GPIO+1
ON&OFF-2 ( pin -- )	Example of PIN? and MOV, GPIO+1 on/off
ON&OFF-1 ( pin -- )	Idem 2, example of PIN? WAIT, and MOV,
PWM-1 ( sm pio pin -- )	1000 Hz PWM, range 0 to 100
PWM-2 ( sm pio pin -- )	1000 Hz PWM, range 0 to 200
PWM-3 ( sm pio pin -- )	1000 Hz PWM, range 0 to 400
PWM-4 ( sm pio pin -- )	10000 Hz PWM, range 0 to 400
ROTARY-0 ( pin -- )	Rotary encoder on GPIO to GPIO+3
ENCODER-DEMO ( -- )	Encoder demo on GPIO26 to GPIO29
SPI-0 ( sm pio clock pin -- )	SPI I/O using three GPIO pins, clock in KHz 8 data bits and autopull & autopush
SPI-1 ( sm pio clock pin -- )	SPI I/O using four GPIO pins, clock in KHz 8 data bits, PULL, and autopush
SPI-2 ( sm pio clock pin -- )	SPI I/O using four GPIO pins, idem 2 but slightly different Forth usage
SPI-3 ( sm pio clock pin -- )	SPI I/O using four GPIO pins, the chip select is done by the Forth program
SPI-4 ( sm pio clock pin -- )	SPI out using four GPIO pins
SPI-5 ( -- )	SPI I/O using GPIO26 to GPIO29
UART-0 ( -- )	115K2 UART output on GPIO26
UART-1 ( -- )	Dual UART output on GPIO26 = 115K2 & GPIO27 = 38K4 using clone
UART-2 ( -- )	115K2 UART output on SM0 and GPIO26 & input on SM1 and GPIO27

<b>PIO function</b>	<b>Description</b>
UART-3 ( -- )	460K8 UART TX and RX on GPIO26 & GPIO27 adding a simple chat function
UART-4 ( -- )	460K8 alternative UART for noForth
UART-5 ( -- )	9600 baud alternative UART for noForth
WS2812-0 ( pin -- )	Single WS2812 driver at GPIO from stack
WS2812-1 ( sm pio pin -- )	Single WS2812 driver demo & GPIO25 led flasher on two state machines
WS2812-2 ( -- )	Multiple WS2812 driver demo on GPIO23 & GPIO28, on two state machines using clone
WS2812-3 ( -- )	Multiple WS2812 LED on GPIO28 alternative driver demo, with Forth demo program & special functions
WS2812-4 ( -- )	Multiple WS2812 LED on GPIO28 precompiled PIO-program, with Forth demo program & special functions
CARS\ ( -- )	Highway simulation on a string of WS2812 leds (runs in the multitasker!)